



Product Code: 2012 Product Name: Pet Waste Disposal Bags Individual Carton UPC: 624622201241 Individual Carton Shipping Dimensions: 40.6cm W x 16.5cm H x 24.1cm D (16" W x 6.5" H x 9.5" D) Individual Carton Shipping Weight: 6.8 kg (15 lbs)

Site Location: The 2012 pet waste bags are for use in the 2010 pet waste dispenser and are perfect for any area with high traffic pet ownership. These are meant to be used in areas around public parks, condominiums, residential paths, schools/universities, and common courtyard areas.

Features:

- Case of 10 boxes of 200 bags (2,000 bags total per case)
- For use with Frost 2010 dispenser or 2013 pet waste system
- Easily removable from Frost 2010 dispenser
- Two pet waste bag boxes fit in the dispenser (400 total bags)



Characteristics: The 2012 pet waste bags are designed for use with Frost's pet waste station. The 2012 pet waste disposable bags come in a case of ten boxes. Each box includes 200 bags. Two boxes of disposable bags fit into the Frost 2010 pet waste dispenser. These bags are easy to remove from the dispenser and are 8" x 13" (20.3cm x 33cm) in size.

Capacity:

• Bag size is 8" x 13" (20.3cm x 33cm). 200 bags are in each individual box. A case includes 10 individual boxes. There is a total of 2,000 disposable bags in a case.

Materials:

• High density plastic bag, green in colour.

Individual Box Dimensions:

• 8.75"L x 3"D x 3"H (22.2cm L x 7.6cm D x 7.6cm H)

Individual Box Weight:

• 0.7 kg (1.5 lbs)

Installation: Open the Frost 2010 pet waste dispenser using the key provided. Pull front of the dispenser out and up to swing the lid open. Place 1 or 2 boxes of disposable pet waste bags in the unit. The unit will hold 2 pet waste bag boxes at a size of 8.75"L x 3.125"H x 3.125"D each. Close the door to the unit and secure the tumbler lock at the front. If you have trouble locking the unit, simply slightly lift the boxes inside the unit and turn the key in the lock, as the boxes may be interfering with the closing of the lock.

Maintenance:

Normal preventative maintenance and cleaning will keep Frost products functioning properly and may extend normal product life. Products should be wiped down with a damp soft cloth periodically. Approved stainless steel cleaner may be used to clean scuffs or fingerprints on stainless surfaces. Do not use harsh detergents or chemical cleaners. For general dirt and blemishes on painted steel or plastic use warm water and mild soap, or a general mild cleaning solution.

Frost Products Ltd 5276 John Lucas Drive Burlington, ON, Canada, L7L5Z9

(905) 332-5700 1-800 667-5094 info@frostproductsltd.com www.Frostproductsltd.com



Specification Information

When using any type of cleaning solution, spray onto a discrete area to test before full usage. After the cleaning agent is applied, wipe off with a clean soft cloth or sponge.

Warranty:

If any product or part proves to be defective within 12 months from date of shipment from the factory it will be repaired or replaced without any charge including freight costs when authorized. Costs resulting from the installation or removal of defective products are not covered under this warranty. Discolouration to stainless steel parts resulting from exposure to harsh environmental and / or chemicals are not considered to be defects in workmanship or material and are not covered under warranty.